
# JRGT01-3.6V


1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
21-1
21-2
21-3
21-4
21-5
21-6
21-7
21-8
22
22-1
22-2
22-3
23
24
25

| AC-2608H Spare Parts | | |
|---|---|---|
| Item No | DESCRIPTION | |
| 1 | Left case | |
| 2 | Decorative cover | |
| 3 | Motor | |
| 4 | Lock twist | |
| 5 | Locking torsion springs | |
| 6 | Right case | |
| 7 | Pcb | |
| 8 | Nickel flakes | |
| 9 | battery | |
| 9-1 | EVA pads | |
| 10 | EVA retaining pads | |
| 11 | Motor teeth | |
| 12 | Sponge blocks | |
| 13 | gearbox | |
| 13-1 | Twin gear shafts | |
| 13-2 | Large gear shaft | |
| 14 | Motor screws | |
| 15 | Double-toothed | |
| 16 | Gear springs | |
| 17 | Friction pads | |
| 18 | Big gear | |
| 18-1 | Eccentric blocks | |
| 19 | trigger | |
| 20 | Chassis screws | |
| 21 | Lawn clip assembly | |
| 21-1 | screw | |
| 21-2 | Flat pads | |
| 21-3 | Positioning sleeve | |
| 21-4 | Cut the grass on the blade | |
| 21-5 | Mowing guide sleeve | |
| 21-6 | Base lock | |
| 21-7 | Locking wire | |
| 21-8 | base | |
| 22 | Pruning knife assembly | |
| 22-1 | Prune on the blade | |
| 22-2 | Pruning guide sleeve | |
| 22-3 | Prune the blade under it | |
| 23 | Lawn clip set | |
| 24 | Pruning knife set | |
| 25 | Charging cable | |
| 26 | Roller oil | |