


PARTS CATALOGUE





Part No.	Spare Part Name	Qty
1	Wire retainer	1
2	Wire retainer	1
3	lock ring	1
4	Spring	1
5	Spring seat	1
6	Steel ball frame	1
7	Screw ST5X40	4
8	Label	1
9	Front housing	1
10	Large oil seal	1
11	Needle bearing HK3012	1
12	Stretch sleeve	1
13	Gasket	1
14	Positioning circlip	1
15	Big gasket	1
16	Spring	1
17	Trip tooth	1
18	Large swivel sleeve	1
19	Drive pin $\Phi 2.5 \times 12$	3
20	Trip disc	1
21	Wire retainer $\Phi 30 \times \Phi 1.5$	1
22	Small oil seal	1
23	Stop ring	1
24	Hammer rod	1
25	Anterior sleeve	1
26	O-ring $\Phi 24.8 \times \Phi 4.4$	1
27	Z-pin	1
28	O-ring $\Phi 16 \times \Phi 2.5$	1
29	Knob	1
30	Knob Spring	1


Part No.	Spare Part Name	Qty
31	Button	1
32	O-ring $\Phi 16 \times \Phi 3.5$	1
33	Rear limit sleeve	1
34	Wire retainer $\Phi 25 \times \Phi 2$	1
35	Front cover	1
36	Quick change sleeve	1
37	Chuck screw	1
38	Quick chuck	1
40	Punch hammer	1
41	O-ring $\Phi 15 \times \Phi 3$	1
42	Aluminum piston	1
43	Piston pin	1
44	Piston pin gasket	2
45	Needle bearing HK0709	1
46	Gasket	1
47	Middle shaft	1
48	Screw ST4.2x14-C	1
49	Torsion spring seat	1
50	Torsion spring	1
51	Deep groove ball bearing 699	1
52	Wire retainer $\Phi 10 \times \Phi 1$	1
53	Needle bearing HK0910	1
54	Bearing	1
55	Holder	1
56	First gear	1
57	Spring	1
58	Spring seat	1
59	Rivet	1
60	Intermediate steel sleeve	1

Part No.	Spare Part Name	Qty
61	O-ring $\Phi 67 \times \Phi 7$	1
62	U-shaped pressure fork	1
63	Bracket	1
64	O-ring $\Phi 28 \times \Phi 2.4$	1
65	Deep groove ball bearing 609-2RS	1
66	Cable pressing plate	1
67	Screw M4x10	2
68	Rotor	1
69	Retaining ring	1
70	Deep groove ball bearing 607-2RZ	1
71	607 Bearing sleeve	1
72	Windshield ring	1
73	Screw ST4x16	2
74	Stator	1
75	Motor housing	1
76	Switch	1
77	Screw ST4x16	2
78	Cable pressing plate	1
79	Indicator lamp(N/A)	1
80	Cable sheath	1
81	Cable plug	1
82	Screw ST3x6	4
83	Carbon brush	2
84	Brush holder	2
85	Spring	2
86	Switch	1
87	Housing cover	1
88	Screw ST4x14	8

26MM ELECTRIC ROTARY HAMMER SPARE PARTS

1 	2 	3 	4 	5 	6 	7 	8 
Wire retainer	Wire retainer	Lock ring	Spring	Spring seat	Steel ball frame	Screw ST5X40	N/A
9 	10 	11 	12 	13 	14 	15 	16 
Front housing	Large oil seal	Needle bearing HK3012	Stretch sleeve	Gasket	Positioning circlip	Big gasket	Spring
17 	18 	19 	20 	21 	22 	23 	24 
Trip tooth	Large swivel sleeve	Drive pin Φ2.5x12	Trip disc	Wire retainer	Small oil seal	Stop ring	Hammer rod
25 	26 	27 	28 	29 	30 	31 	32 
Anterior sleeve	O-ring Φ24.8xΦ4.4	Z-pin	O-ring Φ16xΦ2.5	Knob	Knob Spring	Button	O-ring Φ16xΦ3.5

33 	34 	35 	36 	37 	38 	40 	41 
Rear limit sleeve	Wire retainer	Front cover	Quick change sleeve	Chuck screw	Quick chuck	Punch hammer	O-ring Φ15xΦ3
42 	43 	44 	45 	46 	47 	48 	49 
Aluminum piston	Piston pin	Piston pin gasket	Needle bearing HK0709	Gasket	Middle shaft	Screw ST4.2x14-C	Torsion spring seat
50 	51 	52 	53 	54 	55 	56 	57 
Torsion spring	Deep groove ball bearing 699	Wire retainer	Needle bearing HK0910	Bearing	Holder	First gear	Spring
58 	59 	60 	61 	62 	63 	64 	65 
Spring seat	Rivet	Intermediate steel sleeve	O-ring Φ67xΦ7	U-shaped pressure fork	Bracket	O-ring Φ28xΦ2.4	Deep groove ball bearing 609-2RS

66	67	68	69	70	71	72	73
							
Cable pressing plate	Screw M4x10	Rotor	Retaining ring	Deep groove ball bearing 607-2RZ	607 Bearing sleeve	Windshield ring	Screw ST4x16
74	75	76	77	78	79	80	81
							
Stator	Motor housing	Switch push block	Screw ST4x16	Cable pressing plate	Indicator lamp(N/A)	Cable sheath	Cable plug
82	83	84	85	86	87	88	
							
Screw ST3x6	Carbon brush	Brush holder	Spring	Switch	Housing cover	Screw ST4x14	