

PARTS DIAGRAM


LB11000E－A




序号 NO.	编码代号 Code	零部件名称 Part name		数量 quantity
1	480202	曲轴箱体	CRANKCASE	1
2	94031	平垫 Φ38.5×Φ64×1	FLAT WASHER Φ38.6×Φ64×1	2
3	93530	曲轴油封	CRANKCASE OIL SEAL	2
4	93515	摆杆油封	SWING ROD OIL SEAL	1
5	483901	摆杆	RACKING BAR	1
6	96805	摆杆垫片	SWINGING ROD GASKET	1
7	263902	止退夹	RETAINING CLIP	1
8	269901	橡胶运线块	RUBBER CABLE BLOCK	1
9	91817	放油螺栓	OIL DRAIN BOLT	1
10	94004	放油螺栓垫圈	OIL DRAIN BOLT WASHER	1
11	485601-313	机油尺组件	DIPSTICK	1
12	264301	离心调速器齿轮组件	CENTRIFUGAL GOVERNOR GEAR ASSEMBLY	1
13	480020	曲轴	CRANKSHAFT	1
14	480302	平衡轴	BALANCE SHAFT	1
15	240903	曲轴箱定位销	CRANKCASE LOCATING PIN	2
16	480101	曲轴箱盖	CRANKCASE COVER	1
17	96357	曲轴箱密封垫	CRANKCASE SEAL WASHER	1
18	91349	带量螺栓 M8X40	BOLT M8X40	10
19	485101	油压传感器	OIL PRESSURE SENSOR	1
20	449909	机油过滤器	OIL FILTER	1
21	487701	机油泵组件	OIL PUMP ASSEMBLY	1
22	399912	机油泵盖板密封圈	SEAL RING	1
23	91325	带量螺栓 M6*12	BOLT M6*12	14
24	394200	泄压阀弹簧	PRESSURE RELIEF VALVE SPRING	1
25	329905	钢球	STEEL BALL	1
26	440601	泄压阀盖板	RELIEF VALVE COVER PLATE	1
27	94160	油腔密封圈	OIL CHAMBER SEALING RING	1
28	94241	平垫 10.2×17×1	FLAT WASHER 10.2×17×1	1
29	266102	气门挺柱	VALVE LIFTER	2
30	482001	凸轮轴组件	CAMSHAFT ASSEMBLY	1
31	481901	气门推杆	PUSH ROD	2
32	484001	调速臂	SPEED REGULATING ARM	1
33	484401	调速控制器	SPEED CONTROLLER	1
34	482701	油门拉杆	THROTTLE LEVER	1
35	264201	做调速C簧	SPRING C	1
36	484101	调速B簧	SPRING B	1
37	481202	活塞	PISTON	1
38	481601	活塞环组件	PISTON RING ASSEMBLY	1
39	481501	连杆组件	CONNECTING ROD ASSEMBLY	1
40	486501	活塞销	PISTON PIN	1
41	261301	活塞销挡圈	PISTON PIN RING	2
42	97108	火花塞	SPARK PULG	1
43	481003	气缸头	CYLINDER HEAD	1
44	481701	进气门	INTAKE VALVE	1
45	485901	排气门	EXHAUST VALVE	1
46	93513	气门油封	VALVE SEAL	2
47	486001	气门弹簧	VALVE SPRING	2
48	260802	气门锁夹	VALVE LOCK CLAMP	4
49	261805	排气门弹簧座	AIR INLET SPRING SEAT	2
50	261806	顶帽	TOP CAP	2
51	482102	摇臂	ROCKING ARM	2
52	482101	摇臂轴	ROCKER SHAFT	2
53	92158	螺钉 M5*25	SCREW M5*25	2
54	91017	进气双头螺栓	AIR INLET STUD STUD BOLT	2
55	91007	排气双头螺栓	AIR EXHAUST STUD STUD BOLT	2
56	96290	排气密封垫	EXHAUST SEAL WASHER	1
57	95249	消声器连接管	MUFFLER CONNECTING PIPE	1
58	94205	弹垫 Φ8	SPRING WASHER φ8	2
59	90011	螺母 M8	NUT M8	2
60	380901	缸头定位销	CYLINDER HEAD LOCATING PIN	2
61	96294	气缸头密封垫	CYLINDER HEAD GASKET	1
62	91995	带量螺栓 M12×1.5x90	BOLT M12×1.5x90	4
63	480501	缸头导风罩	CYLINDER HEAD AIR GUIDE COVER	1
64	480502	缸头侧导风罩	CYLINDER HEAD SIDE AIR GUIDE COVER	1
65	96273	进气密封垫	INTAKE SEALING WASHER	1
66	482301	化油器连接块	CARBURETOR CONNECTION BLOCK	1
67	481102	缸头盖	CYLINDER HEAD COVER	1
68	95066	废气管	BLAST PIPE	1
69	96272	缸头盖密封垫	HEADCOVER SEAL WASHER	1
70	91366	螺栓 M6*18	BOLT M6*18	4
71	482812	化油器组件	CARBURETOR ASSY	1
72	96278	化油器密封垫	CARBURATOR WASHER	1
73	480602	油网	FUEL TANK FILTER	1
74	94435	燃油管卡圈 Φ13*1.2	FUEL HOSE CLIP φ13*1.2	1
75	96915	燃油管 Φ4×Φ8×185mm	FUEL HOSE Φ4×Φ8×185mm	1
76	94403	燃油管卡圈 Φ7.5	FUEL HOSE CLIP Φ7.5	1
77	90016	带量螺母 M6	NUT M6	2
78	482902	空气滤清器组件	AIR CLEANER ASSEMBLY	1
79	96277	空滤器密封垫	AIR FILTER GASKET	1
80	97675	点火器组件	IGNITION COIL ASSEMBLY	1
81	91369	带量螺栓 M6X25	BOLT M6X25	2
82	480402	飞轮组件	FLYWHEEL	1
83	484601	叶轮	IMPELLER	1
84	484501	启动杯	STARTER PULLY	1
85	90004	飞轮螺母 M16*1.5	FLYWHEEL NUT M16*1.5	1
86	484701-010	启动器组件	STARTER ASSEMBLY	1
87	260801	Q型线卡	Q-TYPE LINE CARD	2
88	92217	螺栓组件 M4*8	CROSS SCREW STUD M4*8	4
89	350602	呼吸阀组件	BREATHING VALVE ASSEMBLY	1
90	97466	启动电机总成	STARTING MOTOR ASSEMBLY	1
91	91345	带量螺栓 M8*25	BOLT M8*25	2
92	91333	带量螺栓 M6*28	BOLT M6*28	2
93	97209	充电线圈	CHARGE COIL	1
96	94423	燃油管卡圈 Φ9	CLIP,FUEL LINE Φ9	1
97	516403	过滤器	FILTER,FUEL	1
98	94453	胶纤管	FIBERGLASS PIPE	1
99	489901	空滤器支架	AIR FILTER BRACKET	1
100	99033	火花塞套筒	SPARK PLUG SLEEVE	1




Number	English	Chinese
5	Control panel	控制面板
4	Electrical machine	电机
3	Frame parts	机架部件
2	Fuel tank parts	油箱部件
1	Engine	发动机




3	Bolt M6×25	螺栓M6×25	6	Fuel Meter	油位表			
2	Rubber gasket	？垫	5	Filter net	滤网	8	Fuel switch	油开关
1	Fuel tank	油箱	4	Fuel tank Cover	油箱盖	1	Bolt M5×12	螺栓 M5×12
Number	English	Chinese	Number	English	Chinese	Number	English	Chinese



5	Tyre	轮胎	10	Rubber feet	橡胶脚			
4	Wheel shaft	轮轴	9	Support feet	支撑脚	14	Bolt M6×45	螺栓M6×45
3	Support feet	压板	8	Nut M8	螺母M8	13	Bolt M6×12	螺栓M6x12
2	Nut M12×1.75	螺母M12×1.75	7	Guard ban	防护板	12	Shake Feet	减震脚
1	Frame	机架	6	handle	手柄	11	Bolt M8×15	螺栓M8×15
Number	English	Chinese	Number	English	Chinese	Number	English	Chinese



4	Muffler holder	消声器支架	8	Bolt M5×12	螺栓 M5×12	12	Rotor bolt	转子螺栓
3	Bolt M8×12	螺栓 M8×12	7	Junction Box	接线柱	11	Generator End Bell	电机支架
2	Stator	定子	6	Carbon brush	碳刷	10	AdjustVoltageRegulator	调压器
1	Rotor	转子	5	Stator bolt	定子螺栓	9	Back Cover	后盖
Number	English	Chinese	Number	English	Chinese	Number	English	Chinese



4	230V Breaker	230V断路器	8	12V Socket	12V插座
3	Electrical switch	电启动开关	7	12V Breaker	12V 保护器
2	Voltage meter	电压表	6	Panel back cover	面板后盖
1	Control panel	控制面板	5	230V Socket	230V插座
Number	English	Chinese	Number	English	Chinese